

Data Projection System

McIntyre 107

Main Power for the podium remains ON.
Laptop Cable and Computer are attached to the Data Projection System.
VCR is connected to the projector and to TV.

TURNING ON PROJECTOR: Press ON button once.

Projector Remote is located on the Podium.

The bulb takes a minute to warm up before responding. If you're unsure whether projector is on, look up at the projector lens to see if the light is on.

DELL COMPUTER:

- Turn on computer (through cutout on the left side of the podium).
- Select **PC** on the Extron Switcher.
- Press the **RGB** button on the Projector Remote until **RGB1** is displayed on the screen.

LAPTOP COMPUTER:

- Select **LAPTOP** on the Extron Switcher.
- Laptop Cable is located on top of the Podium.
- Attach laptop cable to laptop, and then turn on and boot up Laptop.
- Press **RGB** button on the Projector Remote until **RGB1** is displayed on the screen.
- Internet Access located on wall.
- There is no sound available for the laptop.

VCR:

- Turn on TV. **VIDEO** should display in upper left of TV screen.
- Insert video tap and press PLAY >.

Alternatively

- Turn on projector.
- Press **VIDEO** button on the Projector Remote until **RGB1** is displayed on the screen.
- Audio will come through TV and projector both.

TURNING OFF PROJECTOR: Press ON button TWICE on the remote.

The first time asks if you are sure you want to turn it off.

Getting Additional Help

For immediate help, call the OIS Helpdesk x8585.
For problems with tables, chairs, chalk, heating, lighting, etc., contact Facilities Services x3231.